



NOTES:
When using a vapour permeable (LR) underlay, Forticrete in line with BS5250 recommend that the batten cavity is ventilated from eave to ridge.

Underlay should be positioned beneath undercloak strip.

REV: NOTES:	DATE: 09/02/2018	BY: DA
TITLE: PAN8 - Verge Morta Bedded Verge Detail		
SCALE: 1:5 at A3	DWG NO: FC-0261	REV: A