



- 1: Grade slates into 3 or 4 groups of equal thickness.
- 2: Lay thicker slates at eaves, thinner towards the ridge.
- 3: Lay slates of equal thickness in the same course.
- 4: Sort slates in each group so that thin end of slates will be towards the ridge.
- 5: Hole slates from the rear.

CEMBRIT LIMITED
 SLATE TO ABUTMENT WALL TYPICAL DETAIL
 508x254 GLENDYNE (NATURAL SLATE)
 DRG No. 600 H62/105, 280 and 660