

www.forticrete.com



NOTES: When using a vapour permeable (LR) underlay, Forticrete in line with BS5250 recommend that the batten cavity is ventilated from eave to ridge.



## Forticrete