



Note: When using a vapour permeable (LR) underlay, Forticrete in line with BS5250 recommend that the batten cavity is ventilated from eave to ridge



Technical Helpline 01525 244950 www.forticrete.com

