

Counter-battens nailed to rafters through underlay, sealed using Klover Butylon® tape

Permo® vapour permeable underlay

Eaves Closer

Underlay support tray

Note:  
Counter-battens are needed  
when underlay is tightly stretched  
to create a water channel

Vapour control layer / air barrier  
e.g. Klover Wallint® 50 or Klover Wallint® solar with  
joints sealed using Klover Permo® TR adhesive tape

**KLOBER**  
**AIRTIGHTNESS DETAIL - WARM ROOF WITH NON VENTILATED LOFT**  
**DRG No. KL012**