




BeamClamp
Two UB's connecting to column end plate

This block is a typical type of BeamClamp steelwork connection for illustration purposes only. Please refer to our technical catalogue and/or web site for all available sizes and technical information on loading capacities. To make specifying even easier please visit our on line design tool for steelwork fixings that will detail your exact connection for you at www.beamclamp.com/resources/beamclamp-configurator

Kee Safety Ltd
Web site: www.beamclamp.com
Email: sales@beamclamp.com
T: 0044 (0) 1384 632188
F: 0044 (0) 1384 632192

